


Cooling Tower Control & Dosing Brominator Tools

Ordering Code	Description
SP-BROM-TOOL-LID-LLR	PVC Tool to Open or Close BROM brominator Lid Lockring and to lever brominator lid out of brominator canister
SP-BROM-TOOL-RV-ARV	PVC Tool to Open or Close bowl on RV Strainer 1 inch or 1-1/4 inch size or to Open or Close Air Release valve on lid of BROM brominator



SP-BROM-TOOL-LID-LLR




SP-BROM-TOOL-RV-ARV


STEP 1: Loosen Air Release Valve to Relieve Pressure



STEP 2: Loosen Locking



STEP 3: Lift Brominator Lid



STEP 4: Remove Locking and Lid

