

SPARE PARTS LIST


DP-CA-RXB-CAB
DP-CA-RXPP-CAB
DP-CA-RXP-CAB

DP-CAPH-RXB-CAB
DP-CAPHP-RXP-CAB
DP-CAPHP-RXPP-CAB



**Convergent
Water
Controls**

v1.1



Item No	Part No	Description
1	WA OPF10-PBN10-1.5m	ORP Probe (Threaded type that can replace WA SOTA)
2	WA OPF10-NNN-1.5m	pH Probe (Threaded type that can replace WA SOTA)
3	SP-DCON-P10AT-P	Conductivity Probe
4	SP-AF04-3/4-NX-BNC	Flow Switch (Excludes Acrylic Block)
5	SP-SK-PE-1.3-G-PLUG	Replacement SEKO PE-1.3 pump with 3 pin lead
6	SP-DCON-P10AT-PL	Conductivity Probe lead
7	SP-SK-02B-BK	Black Discharge tubing 2m
8	SP-SK-02A	Clear Soft PVC Suction Tubing 2m
9	SP-SK-04	SEKO weighted foot filter
10	SP-SK-06	SEKO PE-1.3 Roller block
11	SP-SK-01A-BK	SEKO Black PE-1.3 squeeze tube
12	SP-SOL-1/2-S	1/2" Solenoid Valve
13	SP-CV-INT-3/4	Internal Check Valve Cartridge
14	SP-DCON-CMR	Ground Probe
15	SP-SK-03A	Injection Valve (Spring loaded)