

SPARE PARTS LIST


EMEC FCO 05 10 EP

EMEC FCO 05 10 FP



**Convergent
Water
Controls**

v1.0



Item No	Part No - EP Pump	Part No - FP Pump	Description
1	EMEC 074.0186.1	EMEC 074.0166.1	Foot Valve
2	EMEC 059.0003.0	EMEC 059.0003.0	Suction Tubing per Metre
3	EMEC 025.0603.1	EMEC 025.0576.1	Manual Bleed Valve
4	EMEC 026.0002.0	EMEC 026.0013.0	Head O-Ring
4	EMEC 018.0004.0	EMEC 018.0004.0	Diaphragm
5	EMEC 020.1133.1	EMEC 020.0819.1	Pump head - includes Suction, Discharge, Bleed valves and O-Rings
6	EMEC 025.0436.1	EMEC 025.0459.1	Suction / Discharge Valve
7	SP-TB-0604-XXX	SP-TB-0604-XXX	Discharge Tubing per Metre
8	EMEC 073.0254.1	EMEC 073.0237.1	Injection Valve
	EMEC 110.0634.1	EMEC 110.0635.1	Maintenance kit - Includes Suction/Discharge valves, valve for foot filter, Injection valve, O-ring for pump head and all replacement bolts and washers