

SPARE PARTS LIST


EMEC KAPLUS 18 01 PMMA
EMEC KAPLUS 10 3.5 PMMA
EMEC KAPLUS 05 7.5 PMMA

EMEC KAPLUS 18 01 PMMA CLO2
EMEC KAPLUS 10 3.5 PMMA CLO2
EMEC KAPLUS 05 7.5 PMMA CLO2



Convergent
Water
Controls

v1.0



Item No	Part No	Description
1	EMEC 074.0656.1	Foot Valve without float or low level switch
2	EMEC 059.0003.0	Suction Tubing per Metre
3	EMEC 025.1484.1	Suction Valve
4	EMEC 020.1779.1	Pump head - includes Suction, Discharge, Bleed valves and O-Rings
5	EMEC 025.1493.1	Delivery Valve
6	EMEC 025.1485.1	De-Gassing (self-venting) Valve
7	EMEC 026.0415.0	Head O-Ring
7	EMEC 018.0033.0	Diaphragm
8	SP-TB-0604-XXX	Delivery Tubing per Metre
9	EMEC 073.1316.1	Injection Valve
	EMEC 110.0942.1	Maintenance kit - Includes Suction, delivery and de-gassing valves, valve for foot filter, Injection valve, O-ring for pump head and all replacement bolts and washers