

SPARE PARTS LIST



**Convergent
Water
Controls**

v1.0

EMEC VCO 03 10 EP + FP
EMEC VCO 07 06 EP + FP
EMEC VCO 07 06 FP 12VDC
EMEC VCO 15 02 EP + FP
EMEC VCO EXSIL 03 10 FP
EMEC VCO EXSIL 05 05 FP

EMEC VMF 03 10 EP + FP
EMEC VMF 05 01 EP + FP
EMEC VMF 07 06 EP + FP
EMEC VMF 15 02 EP + FP

EMEC VPH 02 17 FP
EMEC VPH 04 08 FP
EMEC VPH 05 01 EP
EMEC VPH 07 06 EP + FP
EMEC VRH 02 17 FP



Item No	Part No - EP	Part No - FP	Description
1	EMEC 074.0571.1	EMEC 074.0570.1	Foot Valve without float or low level switch
2	EMEC 059.0003.0	EMEC 059.0003.0	Suction Tubing
3	EMEC 018.0001.0	EMEC 018.0001.0	Diaphragm
3	EMEC 026.0007.0	EMEC 026.0009.0	Head O-Ring
4	EMEC 020.0988.1	EMEC 020.0987.1	Pump head - includes Suction, Discharge, Bleed valves and O-Rings
5	SP-TB-0604-XXX	SP-TB-0604-XXX	Discharge Tubing per Metre
6	EMEC 073.0254.1 or EMEC 073.1065.1	EMEC 073.0237.1 or EMEC 073.1062.1	Injection Valve
	EMEC 110.0624.1	EMEC 110.0625.1	Maintenance kit - Includes complete pump head, valve for foot filter, Injection valve, O-ring for pump head and all replacement bolts and washers