

SPARE PARTS LIST


EMEC WDPHRH 0706 0307

EMEC WDPHCL 0310 0307



**Convergent
Water
Controls**

v1.0



Item No	Part No Acid Pump	Part No Chlorine Pump	Description
1	EMEC 074.0570.1	EMEC 074.0570.1	Foot Valve without float or low level switch
2	EMEC 059.0003.0	EMEC 059.0003.0	Suction Tubing per Metre
3	EMEC 026.0009.0	EMEC 026.0009.0	Head O-Ring
3	EMEC 018.0001.0	EMEC 018.0001.0	Diaphragm
4	EMEC 020.0987.1	EMEC 020.1015.1	Pump head - includes Suction, Discharge, Bleed valves and O-Rings
5	SP-TB-0604B-XXX	SP-TB-0604B-XXX	Discharge Tubing per Metre
6	EMEC 073.0237.1 or EMEC 073.1062.1	EMEC 073.0237.1 or EMEC 073.1062.1	Injection Valve
	EMEC 110.0625.1	EMEC 110.0627.1	Maintenance kit - Includes complete pump head, valve for foot filter, Injection valve, O-ring for pump head and all replacement bolts and washers

Convergent Water Controls Pty Ltd ABN 58 082 819 734

P O Box 7058, 2/4 Huntley St, Alexandria NSW 2015, Australia

E info@cw.com.au | W www.cw.com.au | Sales 1800 137 954

NSW	T 02 9698 3131	F 02 9698 3210
VIC	T 03 9547 1811	F 03 9547 4606
QLD	T 0439 444 655	F 02 9698 3210