



SPARE PARTS LIST

AT200BB
T200BB



Item No	Part No	Description
1	SP-JS5-GV-BR	Globe Valve 1/2"
2	SP-JS5-HN-1/2	Hex Nipple 1/2"
3	SP-JS5-S-1/2	Strainer 1/2"
4	SP-JS5-RHN-1/2-3/8	Reducing Nipple 1/2" X 3/8"
5	SP-JS5-SOL-3/8	Solenoid Valve 3/8"
6	SP-JS5-CHK	Check valve 1/2"