

SPARE PARTS LIST


EMEC KPLUS 02 18 EP

EMEC KPLUS 02 18 FP



**Convergent
Water
Controls**

v1.0



Item No	Part No - EP Pump	Part No - FP Pump	Description
1	EMEC 074.0597.1	EMEC 074.0577.1	Foot Valve without float or low level switch
2	SP-TB-0806N-XXX	SP-TB-0806N-XXX	Suction Tubing per Metre
3	EMEC 025.1256.1	EMEC 025.1255.1	Internal components for Suction Valve
4	EMEC 020.1127.1	EMEC 020.1128.1	Pump head - includes Suction, Discharge, Bleed valves and O-Rings
5	EMEC 025.0895.1	EMEC 025.0894.1	Internal components for Manual Bleed Valve
6	EMEC 025.1258.1	EMEC 025.1257.1	Internal components for Discharge Valve
7	EMEC 026.0007.0	EMEC 026.0009.0	Head O-Ring
7	EMEC 018.0004.0	EMEC 018.0004.0	Diaphragm
8	SP-TB-0806B-XXX	SP-TB-0806B-XXX	Discharge Tubing per Metre
9	EMEC 073.1112.1	EMEC 073.1079.1	Injection Valve
	EMEC 110.0663.1	EMEC 110.0662.1	Maintenance kit - Includes complete pump head, valve for foot filter, Injection valve, O-ring for pump head and all replacement bolts and washers

Convergent Water Controls Pty Ltd ABN 58 082 819 734

P O Box 7058, 2/4 Huntley St, Alexandria NSW 2015, Australia

E info@cw.com.au | **W** www.cw.com.au | **Sales** 1800 137 954

NSW	T	02 9698 3131	F	02 9698 3210
VIC	T	03 9547 1811	F	03 9547 4606
QLD	T	0439 444 655	F	02 9698 3210