


SPARE PARTS LIST

EMEC KPLUS 05 10 FP
EMEC KPLUS 10 05 FP
EMEC KPLUS 18 02 FP

EMEC KPLUS 05 10 EP
EMEC KPLUS 10 05 EP
EMEC KPLUS 18 02 EP



**Convergent
Water
Controls**
v1.0



Item No	Part No - EP Pump	Part No - FP Pump	Description
1	EMEC 074.0571.1	EMEC 074.0570.1	Foot Valve without float of low level switch
2	EMEC 059.0003.0	EMEC 059.0003.0	Suction Tubing per Metre
3	EMEC 025.0906.1	EMEC 025.0811.1	Internal components for Suction Valve
4	EMEC 020.1125.1	EMEC 020.1126.1	Pump head - includes Suction, Discharge, Bleed valves and O-Rings
5	EMEC 025.0895.1	EMEC 020.0894.1	Internal components for Manual Bleed Valve
6	EMEC 025.0907.1	EMEC 025.0812.1	Internal components for Discharge Valve
7	EMEC 026.0007.0	EMEC 026.0009.0	Head O-Ring
7	EMEC 018.0033.0	EMEC 018.0033.0	Diaphragm
8	SP-TB-0604B-XXX	SP-TB-0604B-XXX	Discharge Tubing per Metre
9	EMEC 073.1065.1	EMEC 073.1062.1	Injection Valve
	EMEC 110.0661.1	EMEC 110.0660.1	Maintenance kit - Includes complete pump head, valve for foot filter, Injection valve, O-ring for pump head and all replacement bolts and washers

Convergent Water Controls Pty Ltd ABN 58 082 819 734

P O Box 7058, 2/4 Huntley St, Alexandria NSW 2015, Australia

E info@cw.com.au | **W** www.cw.com.au | **Sales** 1800 137 954

NSW	T 02 9698 3131	F 02 9698 3210
VIC	T 03 9547 1811	F 03 9547 4606
QLD	T 0439 444 655	F 02 9698 3210